
FH005

ROW

OWNER'S MANUAL



! CAUTION

Read all precautions and instructions in this manual before using this equipment

! CAUTION

Read all precautions and instructions in this manual before using this equipment.

Table Of Contents

Important Safety Instructions	3
Instructions	4
Exploded View and Parts List	5
Measurement Guide	7
Assembly Instructions	8
Assembly	9
Maintenance Schedule	13
General Maintenance Information	14
Weight Training Tips	15

Important Safety Instructions

Before beginning any fitness program, you should obtain a complete physical examination from your physician. When using exercise equipment, basic precautions should always be taken, including the following:

- * Read all instructions before using the equipment. These instructions are written to ensure your safety and to protect the unit.
- * Do not allow children on or near the equipment.
- * Use the equipment only for its intended purpose as described in this guide. Do not use accessory attachments that are not recommended by the manufacturer: such attachments might cause injuries.
- * Wear proper exercise clothing and shoes for your workout----no loose clothing.
- * Be careful when getting on or off the equipment.
- * Do not overexert yourself or work to exhaustion.
- * If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
- * Never operate the unit when it has been dropped or damaged.
- * Never drop or insert anything into any opening in the equipment.
- * Always check the unit and its cables before each use. Make sure that all fasteners and cables are secure and in good working condition.
- * Frayed or worn cables can be dangerous and may cause injury. Periodically check these cables for any indication of wear.
- * Keep hands, limbs, loose clothing and long hair well out of the way of moving parts.
- * Do not attempt to lift more weight than you can control safely.
- * Do not use the equipment outdoors.

PERSONAL SAFETY DURING ASSEMBLY


- * Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment.
- * Assemble and operate the equipment on a solid, level surface. Locate the unit a few feet from walls or furniture to provide easy access. The equipment is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise with the equipment.

Instructions

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only our replacement part when servicing. Failure to do so will void your warranty and could result in personal injury.

The equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.

Tools Required



Ratchet Wrench and Socket



Adjustable Wrench



Rubber Mallet




Hex Key Wrench Set

Parts List

NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED.


Item No.	Description	QTY	Item No.	lo. Description	
1	Bottom Frame	1	30	Hexagon socket set screws with flat point M8×6	4
2	Left Upright Frame	1	31	Flat Head Cap Screw M6×16	2
3	Right Upright Frame	1	32	Flat Washerφ13×φ24×1.5	
4	Middle Upright Frame	1	33	Flat Washerφ11×φ20×2	
5	Left Arm Frame	1	35	Nylon lock Nut M8	2
6	Right Arm Frame	1	36	Snap ring Φ48	2
7	Footplate Frame	1	37	Seat cushion	1
8	Weight Horns	2	38	Buffer pad	2
9	Barbell bar	2	39	Cushion U-shaped frame	1
10	cushion adjusting frame	1	40	Seat cushion	1
11	Foot pedal	2	41	Roller	3
12	Middle foot pedal	1	42	Deep groove ball bearing	6
13	Limit axis	2	43	Roller sleeve	3
14	Arm support shaft	2	44	Torsion spring	
15	ф 25 aluminum head	2	45	Adjusting the handle shaft	
16	Aluminum end cap	6	46	bushing	
17	Limit handle gloves	2	47	External Circlips φ12	
18	Arm strength gloves	2	48	handle gloves	
19	Front seat cushion adjustment plate	1	49	Stretch spring	1
20	Rear seat cushion adjustment plate	1	50	Floor mat	4
21	Spacer pad	4	51	Square tube plug	5
22	Φ 48 rate blockage plate	4	52	Pipe plug F75	4
23	Deep groove ball bearing	4	53	Socket Head Cap Screw M12×145	3
24	Flat Head Cap Screw M12×30	4	54	Nylon lock Nut M12	
25	Socket Head Cap Screw M12×30	14	55	Socket Head Cap Screw M10×145	
26	Flat Head Cap Screw M10×25	4	56	Nylon lock Nut M10	
27	Socket Head Cap Screw M10×30	10	57	Limit sleeve	
28	Flat Head Cap Screw M8×15	8	58	Flat Head Cap Screw M10×25	
29	Button Head Cap Screw M8×65	2	59	Socket Head Cap Screw M10×65	2



STEP 1


Note: Hand Tighten Bolts and Nylon Lock Nuts.

Item No.	Description	QTY	Item No.	em No. Description	
1	Bottom Frame	1	1 2 Left Upright Frame		1
3	Right Upright Frame	1	4	Middle Upright Frame	
7	Footplate Frame	1	12	Middle foot pedal	
25	Socket Head Cap Screw M12×30	14	27	Socket Head Cap Screw M10×30	10
28	Flat Head Cap Screw M8×15	8	32	Flat Washerφ13×φ24×1.5	20
33	Flat Washer ϕ 11 \times ϕ 20 \times 2	12			



STEP 2


Item No.	Description	QTY Item No. Description		QTY	
5	Left Arm Frame	1 6 Right Arm Frame		Right Arm Frame	1
8	Weight Horns	2	14	Arm support shaft	2
16	Aluminum end cap	6 22 ф 48 rate blockage plate		ф 48 rate blockage plate	4
23	Deep groove ball bearing	4	26	Flat Head Cap Screw M10×25	4
36	Snap ring Φ48	2	58	Flat Head Cap Screw M10×25	2



STEP 3

Note: Hand Tighten Bolts and Nylon Lock Nuts.


Item No.	Description	QTY	Y Item No. Description		QTY
10	cushion adjusting frame	1	32	Flat Washer ϕ 13 \times ϕ 24 \times 1.5	20
33	Flat Washer $\phi 11 \times \phi 20 \times 2$	12	41	Roller	
42	Deep groove ball bearing	6	43	Roller sleeve	
44	Torsion spring	1	46	bushing	2
47	External Circlips φ12	2	54	Nylon lock Nut M12	3
55	Socket Head Cap Screw M10×145	1	56	Nylon lock Nut M10	1




STEP 4

Note: Wrench Tighten Screws.

Item No.	Description	QTY	Item No.	. Description		
21	Spacer pad	4	27 Socket Head Cap Screw M10×30		10	
33	Flat Washer ϕ 11 \times ϕ 20 \times 2	12	36	Snap ring Φ48		
37	Seat cushion	1	40	Seat cushion	1	
59	Socket Head Cap Screw M10×65	2				



Measurement Guide



Assembly Instructions

Assembly of the equipment takes professional installers about 2 hours. If this is the first time you have assembled this type of equipment, plan to spend more time. It is strongly recommended to assemble the equipment by professional installers. You may find it quicker, safer, easier to assemble this equipment with the help of a friend, as some of components may be large, heavy or awkward to handle alone. It is important that you assemble your product in a clean, clear, uncluttered area. This will enable you to move around the product while you are fitting components and reduce the possibility of injury during assembly.



As with any assembled part, proper alignment and adjustment is critical. While tightening the fasteners, be sure to leave room for adjustments. Do not fully tighten the fasteners until instructed to do so. Be careful to assemble the components in the sequence presented in this guide.

Maintenance Schedule

ROUTINE	COMMERCIAL MAINTENANCE	HOME MAINTENANCE	l	_ATEST	DATE	ENTR	Y	
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY						
Clean; Upholstery	DAILY	WEEKLY						
Inspect; Cables or Belts and their tension	DAILY	WEEKLY			8			
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS		×				
Inspect; All Decals	WEEKLY	3 MONTHS						
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS						
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS						
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS			×			
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS		À				
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY						
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY						
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS						

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

General Maintenance Information

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- * Check all pieces for signs of visible wear or damage.
- * Check springs in snap hooks and pull-pins for proper tension and alignment.
- * If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- * To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- * Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- * Replace ripped or warn upholstery immediately.
- * Keep sharp or pointed objects clear of all upholstery.

Decals:

* Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- * Inspect all nuts and bolts for any loosening and tighten if needed.
- * Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

* These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- * We uses only high quality belt, and mil-spec cables.
- * Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- * While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.
- * Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

Belt and Cable Tension:

- * Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.
- * Check slack in cables and re-adjust cable tension if needed.

Seat Sleeves, Guide Rods:

- * Wipe down adjusting tubes with a dust free rag before applying lubricant.
- * Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

* Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS

Weight Training Tips

Use this manual to guide you through the basic exercises you can perform on your equipment. To gain maximum results and avoid possible injury, consult a fitness professional to develop your complete exercise program.

Always consult your physician before starting any exercise program.

To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your equipment, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.

Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.